

## Installation Instructions M7-1

1. Remove the front plate, retaining the 5 bolts to install the adaptor.
2. With a pair of Vice-Grips grab each pin and gently twist and pull them out.  
(They come out quite easily)
3. Unbolt the lever link from the slide on both sides.
4. Slide the slide off the bed plate. The Pins that hold the slide on the bed plate are spring loaded. Depress both pins in and slide the slide over them.
5. Remove the 2 adjusting screws from the back of the adaptor plate.
6. Slide the slide onto the adaptor plate.
7. Bolt the adaptor in place utilizing the 5 bolts from (1.).
8. Reinstall the adjusting screws to just contact the bed plate and snug the lock nuts.
9. Re-connect the lever links.

Note: The de-linking claw plate is not used for this application and is simply pivoted up and out of the way.

Suggestions or recommendations? Contact us at [Sales@beltfedplus.com](mailto:Sales@beltfedplus.com)