

Installation Instructions M7-3 (Pictured is a M7-2 – Same instructions apply)

1. Remove the front plate, saving the 5 bolts (or in some cases, 3) for return to the original configuration when desired.
2. With a pair of Vice-Grips grab each pin and gently twist and pull them out. (They come out quite easily) Save these for returning to original configuration.
3. Unbolt the lever link from the slide on both sides.
4. Slide the slide off the bed plate. The Pins that hold the slide on the bed plate are spring loaded. Depress both pins in and slide the slide over them.
5. Remove the 2 adjusting screws from the back of the adaptor plate.
6. Slide the slide onto the adaptor plate.
7. Bolt the adaptor (B) and steel front plate (C) in place utilizing the 5 bolts provided.
8. Reinstall the adjusting screws (D) to just contact the bed plate and snug the lock nuts.
9. Re-connect the lever links.
10. Lift the del-linking claw on the slide, place the pusher block (A) on the adaptor plate and swing the de-linker claw to engage the pusher block.

Note: The links should be placed on the plate open side down.

Caution: Be aware that enough leverage is exerted on the links that it is possible to collapse the holding finger at the end of the link.

Suggestions or recommendations? Contact us at Sales@beltfedplus.com

